

KEY FEATURES

- Centralised battery communications**
 - One interface for up to 2 x BlueNova batteries or battery banks.
- CAN-to-RS485 protocol translation**
 - Connects supported BlueNova batteries and inverter systems.
- Intelligent charge & discharge limits**
 - Calculates optimum operating limits.
- Battery health & performance visibility**
 - Real-time data logging & remote monitoring.
- Automated load & discharge control**
 - Includes 2 x configurable relays & optional discharge limiting configuration.



• 2 x Battery banks
• CAN & RS485
• 2 x Relays

TECHNICAL SPECIFICATIONS

GENERAL PRODUCT SPECIFICATIONS

Product designation	MBA / Multi-battery Aggregator
Battery configurations	Up to 2 x independent BlueNova batteries / banks
Enclosure dimensions (W x D x H)	150 x 115 x 25mm (excl. antenna)
Module power supply	Input: 12VDC Connector: Centre positive
Supplied DC converter	Input: 12~100VDC Output: 12VDC (regulated)
Local configuration method	Wi-Fi access point with web-based dashboard

COMMUNICATION & CONNECTIVITY

Battery CAN interfaces	RJ45 "BAT 1-CAN" RJ45 "BAT 2-CAN"
Inverter CAN interface	RJ45 "INV-CAN"
RS485 interface	RJ45 "RS485"
Other interfaces	RJ45 "ETHERNET" Wi-Fi antenna USB service port
CAN battery protocols	SBB™ MKII @250kbps Legacy HC & NG Series @500kbps
RS485 battery protocols	Legacy RacPower BP & DU Series
Documented inverter compatibility	Victron® Studer® SMA® GoodWe® Sunsynk® Voltronic®

MONITORING, PROTECTION & CONTROL FUNCTIONALITIES

Live battery parameters	Voltage Current SoH Avg. temperature
Cell & performance data	Cell voltage extremes Capacity Energy in & out
Charge / discharge limits	Automatically calculated CVL, CCL, DVL & DCL
Multi-bank limit auto-selection	Most conservative limits relayed to inverter
Discharge limit configuration	User-configurable SoC threshold (optional)
Load control components	2 x independent normally-open relay outputs
Relay operating modes	Manual or SoC-controlled; adjustable hysteresis
Relay contact ratings (resistive)	1.6A @230VAC or 3A @30VDC
Module power-loss behaviour	Relay outputs open upon module power loss